

## ASC-16 ◀ADJUSTMENTS▶

### ADJUSTING THE ASC-16 FOR STRAP WIDTH

The ASC-16 can be adjusted for strapping with widths of 1/2", 5/8" or 3/4". The tool is equipped with one of two sets of reversible strap guides. With parts number 46, 47, and 48 the tool can be set for use with either 1/2" or 5/8" strapping. With parts number 52, 53 and 54 the tool can be set for use with 5/8" or 3/4" strapping. Guide sets are stamped "13" for 1/2", "16" for 5/8" and "19" for 3/4".

To change strap width, the three strap guides must be reversed, as follows:

1. Remove screws # 62 from the front and # 59 from the rear of the tool. Turn front and rear guides around and replace the screws. Make sure that the same stamped numbers are exposed on each guide: 13 for 1/2" strap, 16 for 5/8" strap, 19 for 3/4" strap.

2. Unscrew (# 10) and remove the side guide.

**IMPORTANT:** Screw # 10 is now being held in place by a small set screw #56 which must be loosened before the #10 screw can be removed. Turn the tool on its nose and you will see a hole in the base directly under the #10 screw. Loosen this set screw #56 by using a 2mm allen key and then remove the #10 screw. Remove pin # 9 and insert it into the same hole on the opposite side of the guide. Reverse the strap guide and replace it in the tool so that the free end of pin # 9 enters the hole in arm # 11. Replace screw #10 and tighten the set screw #56. The exposed stamped number on the side guide should match the numbers on the front and rear guides.

**NOTE:** *Check the proper execution of Step 2 by squeezing together the lifter handle # 3 and the sealer handle # 2. The strap guide should pivot upward along with the feed wheel assembly.*


### ADJUSTING THE ASC-15 FOR STRAP THICKNESS

The ASC-15 can be used with regular duty strapping from .015" to .023" thick; and high tensile strapping up to .020" thick. The tool can be easily adjusted for strap thickness by loosening Allen Bolt #60 and rotating the Adjustment Plate #35 on the side of the tool. Rotating the adjustment plate will change the depth of the cutter. The Adjustment Plate serves as a wrench to turn a hex-end shaft running through the tool. The opposite end of the shaft is round and has a line scribed on it, as shown below. When the line points straight up, the cutter is at its shallowest position; when the line points straight down the cutter is deepest. The usual setting is about half way between these extremes.

Distributed By:

**Allstrap**

1719 Kenny Rd  
Columbus, OH, 43212



If the adjustment plate is at the end of its travel, remove screw # 60 and reposition plate # 35 so that it is within the desired adjustment range. Replace screw # 60 and repeat the above steps until the desired cutting depth is reached.

**NOTE:** *The tool is set up properly if, after interlocking the strap, the upper strap is cut off cleanly and there is a slight mark on the lower strap.*

### ADJUSTING THE FEEDWHEEL CLEARANCE

The ASC-16 is adjusted from the factory so that there is approximately .010" clearance between the Feedwheel and the Clutch Plug (Bottom Gripper). Setting them close together insures that there is enough pressure to enable the Feedwheel and Gripper to bite into the strapping and operate without slipping.

At the same time, by maintaining a small clearance between the Feedwheel and the Gripper, they are prevented from grinding against each other if the tool is ratcheted without having strapping under the Feedwheel. This maximizes the life of those two parts.

Should it become necessary to adjust the clearance between the Feedwheel # 26 and Bottom Gripper # 25, it is easy done, as follows:

1. Loosen Nut # 66 to the right of the rear strap guide.

This frees the Adjusting Screw # 42.

2. Turn the tool up on its nose, with the bottom of the tool facing you, and squeeze the Feedwheel Support Handle # 3. This will lift the feedwheel Support off the Adjusting Screw # 42.

3. Turn the Adjusting Screw # 42 in the proper direction to increase or decrease the gap between the Feedwheel and the Bottom Gripper.

3. When the gap is properly adjusted, re-tighten the lock nut # 66 to keep the adjusting screw from moving while the tool is being operated.

**NOTE:** *The gap is set properly when a single piece of strapping is gripped tightly between the Feedwheel and the Bottom Gripper, but a piece of paper slides easily between them.*